

DISPLAY SCREEN

A. RAISE & LOWER
HEAD SECTION OF THE BASE

B. RAISE & LOWER
FOOT SECTION OF THE BASE

C. LUMBAR UP/DOWN

D. ZERO GRAVITY

E. ANTI - SNORE

F. RETURN TO FLAT

G. CUSTOM PRESET 1

H. LED LIGHTS ON/OFF

I. CUSTOM PRESET 2

J. MASSAGE

K. HEAD MASSAGE INTENSITY

L. WAVE PATTERN PRESET

M. STOP MASSAGE

N. FOOT MASSAGE INTENSITY

O. MICRO USB CHARGING PORT



CUSTOMER SERVICE: 800-973-8374
CUSTOMERSERVICE@REVERIE.COM

OPERATING INSTRUCTIONS:

NOTE:

All screens will timeout after 5 seconds, 15 seconds if screen is auto-refreshing

HEAD AND FOOT ADJUSTMENTS (A,B)

- Adjusts the head and foot sections to the desired positions.
- Zero Clearance feature allows for the foundation to be placed on the floor without legs and able to adjust all sections [head/foot/lumbar] in a complete motion range without any of the mechanical parts under the bed touching the floor. Basically allows you to use your adjustable bed without legs if desired.

LUMBAR (C)

- Includes a remote controlled adjustable lumbar support section for your back and mid-section.

ZERO GRAVITY (D)

- Allows your legs to be lifted to a position slightly above the chest, which enables blood flow to easily circulate back to the heart, thus reducing stress and fatigue.

ANTI SNORE (E)

- Raises the HEAD slightly for easier breathing.

POWER BASE “FLAT” BUTTON (F)

- Levels the power base to the flat position when the button is pressed and held for at least 3 seconds.

NOTE: The “FLAT” cycle can be interrupted and canceled by pressing the head or foot adjustment buttons (A, B).

PROGRAMMABLE MEMORY POSITIONS (G,I)

You can store 2 personalized memory positions.

- To Set a Memory Position: When in desired position, press and hold Memory button for more than 5 seconds until the LED light flashes 3 times to signal Memory position is stored.
- To recall a Memory Position: Press 1 of the 2 presets.

AMBIENT LIGHTING ON/OFF (H)

- Toggle the lightbulb button for on/off functions.

HEAD AND FOOT MASSAGE CONTROLS (K,N)

- Turns on the corresponding massage unit (starting at intensity 5 of 10)
- Slowly increases or decreases massage intensity. To increase massage intensity, press (+) button. To decrease massage intensity, press (-) button.

NOTE: The lowest setting will turn off the corresponding massage unit.

WAVE MESSAGE PATTERN (L)

- Turns on both head and foot massage motors to the wave 1 preset.

MESSAGE STOP BUTTON (M)

- Press to stop all massage features.

NOTE: The massage feature is designed to automatically shut off after 30 minutes of continuous use.

CHARGING PORT (O)

- To charge remote, plug in the wall charger and connect to the micro usb port.

ADDITIONAL REMOTE FEATURES:

- The Reverie 8T power base uses a Bluetooth® remote control system.
- The included remote is already paired with your power base, so should be operational right out of the box. Please test some of the features to ensure functionality.
- Only replacement remote controls require pairing instruction on following pages. If you find that your remote is not paired with the bed, please follow those Bluetooth pairing instructions.

NOTE: This power base may have minor intermittent performance due to RF Interference. This is a normal operation of the power base and is not a defect.

- The buttons are back-lit, when a button is pressed, to aid the visibility of the remote in low light environments.
- Customers can control the remote without facing the receiver (best transmission range is within 30 feet or 10 meters)
- The 8T remote is equipped with a lithium-ion battery that can be recharged anytime with the included Micro USB wall charger adapter.
- Please fully charge your remote before operating for the first time.

SAFETY:

- If there is an overload weight condition on the head or foot mechanism, the control unit will automatically stop all functions.

- The input transformer voltage is AC 120V 60 HZ, the output voltage is DC 36V 4.2A. When there is a short circuit, a fuse on the transformer will be blown in order to protect the electrical equipment.

ATTENTION: When the above situation occurs, the customer **MUST** seek professional assistance.

NOTICE:

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IMPORTANT NOTE:

- *To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.*

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

CONNECTING ONE BED

[does not include KING or SPLIT KING bed sizes]

STEP 1

Hold Lightbulb button for 3 seconds to start searching.

STEP 2

The remote will only detect one bed and automatically connect.

CONNECTING ONE BED

[KING or SPLIT KING only]

STEP 1

Hold Lightbulb button for 3 seconds to start searching.

STEP 2A

[Select KING]

- Scroll using any of the up/down buttons H/L/F. Select by single-pressing lightbulb button.
- If it detects only 2 control boxes then will automatically connect with both control boxes on your bed.
- If it detects more than 2 control boxes, the LED display will show a list of all available control boxes within range [this usually means you have more than one bed in your house]
- Select desired control boxes you want to connect.

STEP 2B

[Select SPLIT KING]

- Scroll using any of the up/down buttons H/L/F. Select by single-pressing lightbulb button.
- When you choose SPLIT KING, will be asked if want to connect to both sides of bed?
- Select YES and will automatically connect with both sides.
- Select NO, then LED display will show a list of available beds within range.
- Select the desired beds you want to connect.

CONNECTING TWO BEDS

[OTHER - connecting two specific beds]

STEP 2C

[Select OTHER]

- After selecting OTHER you will be shown a list of all available beds and asked to select the beds you wish to connect [remote can show up to 20 beds]
- Select any two beds you wish to connect by single-pressing the lightbulb button.

NOTE: If it cannot detect any beds then will say BED NOT DETECTED.

NOTE:
Please remember to recycle all electronics.